



BN68-08079C-00

Quick Setup Guide

PM32F·PM43F·PM49F·PM55F

PH43F·PH49F·PH55F

• The colour and the appearance may differ depending on the product, and the specifications are subject to change without prior notice to improve the performance.


- Download the user manual from the website for further details.
<http://www.samsung.com/boardsolutions>

Checking the Components

(1) Quick Setup Guide (2) Warranty card (Not available in some locations) (3) Regulatory guide (4) Power cord (5) Batteries (Not available in some locations) (6) Remote control (7) RS232C(IN) adapter (8) Screw (M3L8, 1 piece) (9) USB cover

Contact the vendor where you purchased the product if any components are missing. Components may differ in different locations.

Reverse side



- 01 Connect to a USB memory device.
- 02 Connects to MDC using an RS232C adapter.
- 03 Receives sound from a source device via an audio cable.
- 04 Connects to the audio of a source device.
- 05 Connects to a source device using an HDMI cable.
- 06 DVI IN: Connects to a source device using a DVI cable or HDMI-DVI cable.
RGB IN: Use the (dedicated) D-SUB to DVI cable (or D-SUB cable with D-SUB to DVI adapter) when connecting a PC.
MAGICINFO IN: Use the (dedicated) DP-DVI cable when connecting a network box (sold separately).
- 07 Connects to a source device using a DP cable.
- 08 Connects to another product using a daisy chain (DP port) cable.
- 09 Connects to MDC using a LAN cable.

Troubleshooting Guide

Issues	Solutions
The screen keeps switching on and off.	Check the cable connection between the product and PC, and ensure the connection is secure.
No Signal is displayed on the screen.	Check that the product is connected correctly with a cable. Check that the device connected to the product is powered on.

Specifications

Model Name	PM32F	PM43F / PH43F	PM49F / PH49F	PM55F / PH55F	
Panel	Size	32 CLASS (31.5 inches / 80.1 cm)	43 CLASS (42.5 inches / 107.9 cm)	49 CLASS (48.5 inches / 123.2 cm)	55 CLASS (54.6 inches / 138.7 cm)
	Display area	698.4 mm (H) x 392.85 mm (V)	940.89 mm (H) x 529.25 mm (V)	1073.78 mm (H) x 604.00 mm (V)	1209.6 mm (H) x 680.4 mm (V)
Audio Output	10 W +10 W	10 W +10 W	10 W +10 W	10 W +10 W	
Power Supply	AC 100 to 240 VAC (+/- 10%), 60 / 50 Hz ± 3 Hz Refer to the label at the back of the product as the standard voltage can vary in different countries.				
Environmental considerations	Operating	Temperature : 0 °C – 40 °C (32 °F – 104 °F), With PIM : 10 °C – 40 °C (50 °F – 104 °F) Humidity : 10% – 80%, non-condensing			
	Storage	Temperature : -20 °C – 45 °C (-4 °F – 113 °F) Humidity : 5% – 95%, non-condensing			

- This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- For information on Samsung's environmental commitments and product-specific regulatory obligations, e.g. REACH, WEEE, Batteries, visit http://www.samsung.com/uk/aboutsamsung/samsungelectronics/corporatecitizenship/data_corner.html

Свързване и използване на външно устройство

Вижте описаниата на предходната страница.

- За да използвате стари и нови модели заедно, първо се свържете с търговеца, от когото е закупен продуктът, за да проверите дали са съвместими.
- За връзката използвайте кабел Cat 7 (тип *STP*).
- Екранирана усукана двойка.

Свързване към MDC





За подробности относно използването на програмата MDC, след инсталирането ѝ направете справка в Help (Помощ). Програмата MDC можете да намерите на уеб сайта.

Ръководство за отстраняване на неизправности






Проблеми	Решения
Екранът непрекъснато се включва и изключва.	Проверете кабелната връзка между продукта и компютъра и се уверете, че връзката е сигурна.
На екрана се показва No Signal.	Проверете дали продуктът текущо е свързан с кабел. Проверете дали устройството, свързано към продукта е включено.

- Това е продукт от клас А. В битова среда този продукт може да причини радиомускулция и в този случай може да се изисква от потребителя да вземе адекватни мерки.
- Информация относно ангажиранта към околната среда и специфичните за продукта регулаторни задължения на Samsung, например директивите REACH, WEEE, директивата за батерии, посетете http://www.samsung.com/uk/aboutsamsung/samsungelectronics/corporatecitizenship/data_corner.html

Connecting to a PC



Connecting to a Video Device



Connecting to an Audio System



Connecting to MDC

Connecting an External Monitor

